

When system is off touch anywhere on the welcome screen to navigate to Main Screen.

Displays will power up once a source is selected from the sources menu.

When you are finished using the system press the exit button and confirm system shutdown. Displays will turn off and any screens in use will retract.

- ① -Source Selection- Choose desired source here and it will be routed to both wall displays.
 PC- Select this source to utilize in room PC. Microphones and cameras are accessible to this computer for use in a video call. (IE: Zoom, Teams, Webex)
 Wireless- Select this source to utilize the wireless video connection. When selected, connection instructions will appear on the screen.
 Laptop HDMI- Select this source to utilize the HDMI input wallplate that is located in the center of the room on the front wall.
- ② -Left Projector Activation- Press this button to utilize the projector to your left in the system.
 The screen will drop from the ceiling, projector will turn on and the selected source will display on the screen.
 Press the button again to power down the projector and screen will retract.
- ③ -Right Projector Activation- Press this button to utilize the projector to your right in the system.
 The screen will drop from the ceiling, projector will turn on and the selected source will display on the screen.
 Press the button again to power down the projector and screen will retract.
- ④ -Program Volume- Use these controls to increase, decrease and mute program audio that is coming through the ceiling speakers.
- ⑤ -Speech Volume- Use these controls to increase, decrease and mute microphone audio that is coming through the ceiling speakers.
 This does not effect the audio going across a video call through the PC source.
- ⑥ -Privacy Mute- Use these controls to mute all microphone audio that is going to the PC for use in a video
- ⑦ -Exit- This button will launch the power down pop up. From this page you can confirm you would like to power down the system or return to the main
- ⑧ -Room Controls- Press this button to launch the room controls pages. This will give access to more in depth source routing, audio and display



-Display Controls-


From these controls you can:

- Independently power on and off each display.
- Recall the HDMI 1 input on the displays.
- Mute or "blank" the displays.
- Independently put the screens up or down.



-Audio Controls-

From these controls you can Independently increase, decrease and mute each mic.



-Advanced Routing-

From these controls you can route specific sources to specific displays. This gives you the ability to customize your setup and show multiple sources at one time.

Displays are listed in the left vertical column and sources are listed in the top horizontal column.

Press the button where they meet, then press the "Set Routes" button and that source will be sent to that display.

You can select several source and destination buttons before pressing "Set Routes" and they will all be made at the same time.